

Cell Modem Communication

No Hassle. No Configuration. Stay Connected.

Avoid potential network and hardware failure points with a reliable industrial cell modem installed in the LED display.



What's Required?

A cell modem and a data only plan.

The industrial cell modem is configured and installed in the LED display at the factory. It automatically connects to the T-Mobile data network when power is connected to the display in the field. Open an Internet browser, go to www.sminfinity.com, login, and start programming the display.

- T-Mobile Data plans are sold in yearly increments (\$120 per year).
- Plans come with unlimited data every month.

